



Quick Guide Handmate UV600



Always wear personal safety gear (UV facial shield, gloves and UV protective clothes)

Unprotected bystanders: keep 6 meter distance !

Warning: The bottom of the lamp unit becomes hot!

The DecoRad HandMate UV 600 has a power cable of 60 centimeters. Connect the power cable to an extension cord.

Mains/outlet: 200 – 250 V / 50 – 60 Hz
Fuse: 10 – 16 A

Standard with small handle
(optional) extension handle

Connect the extension handle to the lamp unit

Connect (careful) the data cable of the extension handle to the back of the lamp unit

Press the (power) **ON** button
The indicator light will burn

On the display of the lamp unit the text **DONE** will be shown



Press the button with the **lamp symbol** in order to start up the UV lamp.



Press the button with the lamp symbol.
On the display the text **WAIT** will be shown. As soon as **DIM** is shown in the display, the Handmate UV 600 is ready to use.



Use the button on the lampunit or the extension handle to start UV curing
The shutter opens
On the display of the lamp unit the text **FULL** will be shown



Full power UV can only be used in the safe range of 2 – 4 centimeters to any surface
DIST shown in display = distance to surface is not correct / unsafe, a beeping signal can be heard and the shutter closes.



Move the lamp unit in a position between 2 – 4 centimeters from the surface

Switch off the UV lamp from **DIM** to end curing . The text **COOL** will be shown. After cooling down the text **DONE** will be shown.

Press the (power) **OFF** button



ERROR MESSAGES CHECK MANUAL

E14 LAMP OVERHEATED

E15 FAN FAIL

E16 SHUTTER FAIL

E17 TEMPERATURESENSOR FAIL

U51 DISTANCE TO SUBSTRATE

U94 TIME MANAGEMENT 5 MINUTES

IMPORTANT !

ALWAYS cool a HOT UV lamp

NEVER start up a HOT UV lamp.